



Electromagnetics:  
Electromagnetic Field Theory

## Energy in Electrostatic Fields


### Outline

- Energy in terms of potential
- Energy in terms of the field
- Power and energy in conductors

# Energy in Terms of Potential

Slide 3

## Recall Potential Difference



Recall the relation between potential difference, work, and charge.


$$V_{AB} = V_B - V_A = \frac{W}{Q}$$

Therefore, the work it takes to move charge  $Q$  from A to B is

$$W = QV_{AB}$$

Slide 4


## Energy in an Ensemble of Charges



An ensemble of charges contains energy because the charges are putting a force on each other and so they have the potential to do work.

The energy contained in the ensemble will be determined by calculating how much energy it took to assemble it.


## Point Charge #1



No other charges are present, so placing  $Q_1$  at  $P_1$  takes no work.

$$W_1 = 0$$


## Point Charge #2



Placing  $Q_2$  at  $P_2$  takes work because charge  $Q_1$  is present.

$$W_2 = Q_2 V_{21}$$


## Point Charge #3



Placing  $Q_3$  at  $P_3$  takes work because charges  $Q_1$  and  $Q_2$  are present.

$$W_3 = Q_3 V_{31} + Q_3 V_{32}$$


## Total Work So Far



The total work placing all three charges is

$$\begin{aligned} W &= W_1 + W_2 + W_3 \\ &= 0 + Q_2 V_{21} + Q_3 (V_{31} + V_{32}) \end{aligned}$$

## Assembly in Reverse Order



If the charges were placed in reverse order,

$$\begin{aligned} W &= W_3 + W_2 + W_1 \\ &= 0 + Q_2 V_{23} + Q_1 (V_{12} + V_{13}) \end{aligned}$$

## Add Both Approaches

$$W = 0 + Q_2 V_{21} + Q_3 (V_{31} + V_{32})$$

Equation obtained by placing  $Q_1$ , then  $Q_2$ , and then  $Q_3$ .

$$W = 0 + Q_2 V_{23} + Q_1 (V_{12} + V_{13})$$

Equation obtained by placing  $Q_3$ , then  $Q_2$ , and then  $Q_1$ .

$$2W = 0 + Q_2 V_{21} + Q_3 (V_{31} + V_{32})$$

$$+ 0 + Q_2 V_{23} + Q_1 (V_{12} + V_{13})$$

Add the two equations above.

$$2W = Q_1 \underbrace{(V_{12} + V_{13})}_{V_1} + Q_2 \underbrace{(V_{21} + V_{23})}_{V_2} + Q_3 \underbrace{(V_{31} + V_{32})}_{V_3}$$

Total potentials  $\rightarrow$

$$2W = Q_1 V_1 + Q_2 V_2 + Q_3 V_3$$

## Final Expression

$$2W = Q_1 V_1 + Q_2 V_2 + Q_3 V_3$$

$$W = \frac{1}{2} Q_1 V_1 + \frac{1}{2} Q_2 V_2 + \frac{1}{2} Q_3 V_3$$

Solve for  $W$ .

It is straightforward to generalize this for any number of charges.

$$W = \frac{1}{2} \sum_{i=1}^N Q_i V_i \quad (\text{joules})$$

## Energy in Charge Distributions

### Point Charge

 $Q$ 

Charge

 $Q$  (C)


Total Charge

$$Q_{\text{Total}} = \sum_{i=1}^N Q_i$$

Total Energy

$$W = \frac{1}{2} \sum_{i=1}^N Q_i V_i$$

### Line Charge



Line Charge Density

 $\rho_l$  (C/m)

Total Charge

$$Q_{\text{Total}} = \int_l \rho_l dl \cong \rho_l L$$

Total Energy

$$W = \frac{1}{2} \int_l \rho_l V dl$$

### Sheet Charge



Surface Charge Density

 $\rho_s$  (C/m<sup>2</sup>)


Total Charge

$$Q_{\text{Total}} = \iint_S \rho_s ds \cong \rho_s S$$

Total Energy

$$W = \frac{1}{2} \iint_S \rho_s V ds$$

### Volume Charge



Volume Charge Density

 $\rho_v$  (C/m<sup>3</sup>)

Total Charge

$$Q_{\text{Total}} = \iiint_V \rho_v dv = \rho_v V$$

Total Energy

$$W = \frac{1}{2} \iiint_V \rho_v V dv$$

## Energy in Terms of the Field

## Derivation (1 of 5)

The energy in a volume charge is

$$W = \frac{1}{2} \iiint_{\mathcal{V}} \rho_v V dv$$

Recall from Maxwell's equations that  $\rho_v = \nabla \cdot \vec{D}$ .

$$W = \frac{1}{2} \iiint_{\mathcal{V}} (\nabla \cdot \vec{D}) V dv$$

Recall the product rule for divergence  $\nabla \cdot (f\vec{A}) = f(\nabla \cdot \vec{A}) + \vec{A} \cdot \nabla f$

$$\nabla \cdot (V\vec{D}) = V(\nabla \cdot \vec{D}) + \vec{D} \cdot \nabla V$$

$$(\nabla \cdot \vec{D})V = \nabla \cdot (V\vec{D}) - \vec{D} \cdot \nabla V$$

## Derivation (2 of 5)

Apply the product rule for our equation for work.

$$\begin{aligned} W &= \frac{1}{2} \iiint_{\mathcal{V}} (\nabla \cdot \vec{D}) V dv \\ &= \frac{1}{2} \iiint_{\mathcal{V}} [\nabla \cdot (V\vec{D}) - \vec{D} \cdot \nabla V] dv \\ &= \frac{1}{2} \iiint_{\mathcal{V}} [\nabla \cdot (V\vec{D})] dv - \frac{1}{2} \iiint_{\mathcal{V}} [\vec{D} \cdot \nabla V] dv \end{aligned}$$



## Derivation (3 of 5)

Recall the divergence theorem

$$\oiint_S \vec{F} \cdot d\vec{s} = \iiint_V (\nabla \cdot \vec{F}) dv$$

Apply this to the equation for work.

$$W = \underbrace{\frac{1}{2} \iiint_V [\nabla \cdot (V\vec{D})]}_{\frac{1}{2} \oiint_S (V\vec{D}) \cdot d\vec{s}} dv - \frac{1}{2} \iiint_V [\vec{D} \cdot \nabla V] dv$$

$$W = \frac{1}{2} \oiint_S (V\vec{D}) \cdot d\vec{s} - \frac{1}{2} \iiint_V [\vec{D} \cdot \nabla V] dv$$

## Derivation (4 of 5)

Look more closely at the surface integral.

$$W = \frac{1}{2} \oiint_S (V\vec{D}) \cdot d\vec{s} - \frac{1}{2} \iiint_V [\vec{D} \cdot \nabla V] dv$$

$V \propto \frac{1}{r}$   
 $|\vec{D}| \propto \frac{1}{r^2}$   
 $|d\vec{s}| \propto r^2$

Overall  $\propto \frac{1}{r} \frac{1}{r^2} r^2 = \frac{1}{r}$

Any surface  $S$  can be chosen.

As the surface is enlarged out to infinity, the surface integral becomes negligible relative to the volume integral.

~~$$W = \frac{1}{2} \oiint_S (V\vec{D}) \cdot d\vec{s} - \frac{1}{2} \iiint_V [\vec{D} \cdot \nabla V] dv$$~~

## Derivation (5 of 5)

The equation for work is now

$$W = -\frac{1}{2} \iiint_v [\vec{D} \cdot \nabla V] dv$$

Associate the negative sign with  $\nabla V$ .

$$W = \frac{1}{2} \iiint_v [\vec{D} \cdot (-\nabla V)] dv$$

This is the electric field intensity  $\vec{E}$ .

$$W = \frac{1}{2} \iiint_v (\vec{D} \cdot \vec{E}) dv$$

This is the general equation for energy stored in the electrostatic field.  
It is valid for anisotropic and inhomogeneous media.

## Electrostatic Energy in LHI Media

The more common expression for energy in the electrostatic field is for the special case of linear, homogeneous, and isotropic (LHI) media.

In isotropic media there is  $\vec{D} = \epsilon \vec{E}$ .

$$\begin{aligned} W &= \frac{1}{2} \iiint_v (\vec{D} \cdot \vec{E}) dv \\ &= \frac{1}{2} \iiint_v (\epsilon \vec{E} \cdot \vec{E}) dv \end{aligned}$$

$$W = \frac{1}{2} \iiint_v \epsilon |\vec{E}|^2 dv$$

Simpler equation that is only valid in LHI media.

## Electrostatic Energy Density

Total energy has been being calculated by integrating.

$$W = \iiint_v \left( \frac{1}{2} \vec{D} \cdot \vec{E} \right) dv \qquad W = \iiint_v \left( \frac{1}{2} \varepsilon |\vec{E}|^2 \right) dv$$

These expressions must be energy density  $w$ .

Instead, think of calculating total energy by integrating the energy density  $w$ .

$$W = \iiint_v w dv \qquad w = \begin{cases} \frac{1}{2} \vec{D} \cdot \vec{E} & \text{General case} \\ \frac{1}{2} \varepsilon |\vec{E}|^2 & \text{LHI media} \end{cases}$$

## Power & Energy in Conductors

## Joule's Law

Joule's law calculates the power dissipated by a conducting medium.

$$P = \iiint_v (\vec{E} \cdot \vec{J}) dv \quad \text{This is equivalent to } P = VI \text{ in circuit theory.}$$

From this, the power density  $p_d$  in a conductor is extracted.

$$p_d = \vec{E} \cdot \vec{J}$$

Applying Ohm's law for electromagnetics  $\vec{J} = \sigma \vec{E}$  gives

$$\begin{aligned} p_d &= \vec{E} \cdot \vec{J} \\ &= \vec{E} \cdot \sigma \vec{E} \\ &= \sigma |\vec{E}|^2 \end{aligned}$$

$$P = \iiint_v \sigma |\vec{E}|^2 dv$$

Most common form for power dissipated in a conductor.